

Maintenance & Care



Note on Regular Ventilation of Attic Stairs

To ensure proper function and a long service life of your attic stairs, they should be opened and ventilated regularly. We recommend fully opening the attic stairs at least twice per week. This allows air exchange and helps reduce possible moisture build-up around the stairs, the hatch construction, and the attic space. Please pay particular attention to regular ventilation during the cold season and in periods of high humidity. This helps prevent condensation, material deformation, and other moisture-related damage.

Note on Regular Lubrication of Attic Stairs

To ensure proper function and a long service life of your attic stairs, the moving parts should be oiled at least once per year. This includes, in particular, moving joints, hinges, and bearing points. Use a suitable acid-free lubricant and apply it sparingly. After application, excess oil should be removed with a dry cloth to prevent soiling or dripping.

Note on Regular Inspection and Retightening of Fastenings

Check all screw connections and fastening points at least once per year to ensure they are correctly seated. Screws and fastening elements must generally be firmly tightened. However, at moving connection points, the moving parts must still be able to move freely.

2026	✓
2027	
2028	
2029	
2030	
2031	
2032	
2033	
2034	
2035	
2036	

Maintenance & Care

